



---

# *Index*

## **PROGRAMMING INSTRUCTIONS**

Helpful Hints .....	1
Introduction .....	1
Know Your Thermostat .....	2
Display .....	2
Slide Switches .....	3
Control Buttons .....	3
Selecting your heat/cool system .....	3
Set Your Personal Schedule .....	4
Battery Installation and Thermostat Start Up .....	5
Begin Programming Steps 1 to 11 .....	5 to 9
Skipping a Program .....	7
Using some Special Features .....	10
Fan Operation .....	10
Program Lock .....	10
Remote Sensor .....	10

## **INSTALLATION INSTRUCTIONS**

Thermostat Location .....	11
Connecting Thermostat .....	12
Lights .....	13
Setting Slide Switches .....	14
Battery Installation and Start Up .....	15
Checking Installation .....	15

## **TROUBLE SHOOTING GUIDE**

Trouble Shooting .....	16
Specifications .....	(inside back cover)
Warranty .....	(back cover)

# Programming instructions

## Helpful hints

Please take the few minutes required to read the programming instructions. Experience has shown that users who do read the instructions have no difficulty in programming and using their thermostat. Then find a convenient place for your instruction manual so that you can easily refresh your memory at a later date.


## Introduction

Your new thermostat contains a microcomputer that will automatically adjust the temperature of your home or office, up to four times each day, to save money and energy. It provides comfortable heating or cooling when you need it, and reduces energy expenditure while you are sleeping, or are out of the building, or on vacation. You can program four temperatures into your thermostat. Each temperature can be selected with a different start time for each of the following periods: Sunday, Weekdays, and Saturday. This weekend programming feature called 5-1-1 allows the five weekdays to have the same start times, and then allows two successive days that can each have different times.


You can **OVERRIDE** or **SUPERSEDE** these settings whenever you wish to vary the schedule. If you have guests during the evening and you do not want the temperature to drop while they are visiting, the touch of a finger to your evening setting (for example 70°F or 21°C) will **OVERRIDE** your program and keep the temperature at its current setting until after your guests have gone. In addition, you can keep the temperature at a constant setting for any period from one hour up to 31 days using the **TIMED OVERRIDE** feature, explained on page 9.

We also recommend that everyone in the family read the instructions and, before installation, practice programming the thermostat by inserting the battery and following the programming steps. You will soon know how truly simple it is to operate your thermostat.

The thermostat should then be installed. We recommend that a qualified technician install the thermostat because it is very important that it is properly located and all heating and cooling circuits are wired correctly. For **INSTALLATION INSTRUCTIONS** start on page 11.



# Know your thermostat




- ① The time of day AM or PM and the actual room temperature are displayed alternating at 4 second intervals in normal operation, and the decimal or colon are constantly blinking when temperature and time respectively are shown.
- ① A set temperature and time are displayed when programming. Nothing is blinking. The factory setting for all programs is shown in figure 3a on page 4.
- ① The duration of timed override is displayed. Nothing blinks. (see timed override page 9).  
Note: decimal point is displayed and not a colon as in a time display.
- ② Day of week, shows the 'day indicator' at beginning of 5 day program, typically Monday of the 5 days of the week.
- ③ Mode symbols, indicating system in heating (flame) heating and cooling (flame and icicle) cooling (icicle) emergency heat (flashing flame) or **OFF** mode (no symbols).
- ④ Fan symbol shows when the fan is in the 'on' continuous mode.
- ⑤ Indicators showing from bottom to top: 2nd stage cool, 1st stage cool, 1st stage heat, 2nd stage heat, 3rd stage heat.
- ⑥ Indicates when unit is operating on the battery (thermostat is not installed or the power is off). When battery needs to be replaced, the symbol is flashing.
- ⑦ Indicates the program A,B,C, or D in which the thermostat is operating.

## Slide switches

The slide switches 1 to 10 and the wire loop switch are accessed from the rear of the front unit of the thermostat. They have been preset at the factory for the most frequently used settings and **should only be changed by the installer.**

However, if you wish to review the options, see page 14.

**Figure 2.** Rear view of front unit



## Control buttons

There are Function buttons on the left and Program buttons on the right. Each button has multiple uses.

- Raises temperature, adjusts hours, sets override hours
- Lowers temperature, adjusts minutes, skips program -----
- Advances the day indicator to the correct day of week, sets override days when override is displayed
- Pressing once resumes program  
Pressing a second time displays timed override
- The program buttons A, B, C and D are used to gain access to programs in order to:
  - override to the program
  - change or check the program
- 
- 
- 

Functions	Programs
Raise Temp. Adjust Hrs. Set Override Hrs.	A
Lower Temp. Adjust Mts	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on/auto

Front view

## Selecting your heat/cool system

By consecutively pressing and releasing the button the following symbols will appear:

HEAT    AUTO    EMERGENCY    OFF    COOL

         (no symbols)   


      (flashing)

With no heat or cool symbols displayed, the system is off.

With the fan button , you set the fan to

continuous operation (ON mode) and the fan symbol is displayed. In the 'auto' mode, no fan symbol will be displayed and the fan operates or cycles as the system demands.

Functions	Programs
Raise Temp. Adjust Hrs. Set Override Hrs.	A
Lower Temp. Adjust Mts	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on/auto



# Set your personal schedule

## Typical residential schedule

Figure 3a.

Temperature		Sunday Time AM/PM	Weekdays Time AM/PM	Saturday Time AM/PM
A	Heat 68	8:00 AM	6:00 AM	8:00 AM
	Cool 73			
B	Heat 64	-----	6:00 AM	-----
	Cool 85			
C	Heat 68	-----	3:30 PM	-----
	Cool 73			
D	Heat 62	10:30 PM	10:30 PM	10:30 PM
	Cool 78			

## Typical office schedule

Figure 3b.

Temperature		Sunday Time AM/PM	Weekdays Time AM/PM	Saturday Time AM/PM
A	Heat 70	-----	7:30 AM	-----
	Cool 74			
B	Heat 72	-----	-----	-----
	Cool 76			
C	Heat 68	-----	-----	-----
	Cool 78			
D	Heat 60	10:30 PM	5:00 PM	10:30 PM
	Cool 82			

**NOTE:**

If the thermostat has more than one setting with the same start time, it chooses the first one in alphabetical order.

The first thing to do before programming your thermostat is to determine your own personal comfort levels for each day as to temperature and time. Figure 3a is the factory set schedule and it is typical of residential needs.

On the weekdays after the temperature has been lowered all night, it would be typical to have the thermostat begin to warm the house at 6:00 AM, if you get up at 7:00 AM. At 8:00 AM before everyone has left for the day, the thermostat can be set to lower the temperature to save you energy during the day. Before anyone arrives home in the afternoon, the temperature may again be increased to provide comfort for you when you return. Finally, at bedtime, the thermostat again lowers the temperature to save you energy all night.

On Saturday and Sunday when everyone is home, the temperature comes up to 68°F at 8 AM and stays there all day until 10:30 PM when the temperature sets back to 62°F. The other two temperatures are skipped, but they are still available for OVERRIDE.

Figure 4 is a blank form for your use. Start by selecting your heat/cool temperatures. Now determine the times that you want the temperatures to be active on the weekdays. Write in the desired times in the appropriate place. If you want to skip a temperature, write in four dashes as is done in the typical schedules. Now do the same for Saturday and Sunday.

**NOTE:** It is suggested that you set your desired program times about 1 hour before the time that you actually require your home to reach the set temperature. So if you get up at 7 AM, set the wake up temperature to come on at 6 AM.

## Fill in this chart to help program your schedule

Temperature		Sunday Time AM/PM	Weekdays Time AM/PM	Saturday Time AM/PM
A	Heat			
	Cool			
B	Heat			
	Cool			
C	Heat			
	Cool			
D	Heat			
	Cool			

Figure 4.

# Begin programming

## Battery installation and startup


**CAUTION:** Your microcomputer thermostat, like many modern electronic devices such as office computers, can be disrupted or damaged by static electricity. Although we have taken steps to lessen the thermostat's susceptibility to static electricity, we advise that you discharge any static build-up on your body by touching a metal object before touching your thermostat.


1. Separate the thermostat front unit from the mounting plate (page 12 figure 13).
2. Install the battery (Page 3 figure 2 shows location).
3. Allow a few seconds for the display to start flashing once per second as in figure 5.



Figure 5. Display on start-up


## STEP 1.

Press the  button and observe the time and temperature alternating every 4 seconds.





Actual temperature


Time




## STEP 2. Set correct time of day

When the display is showing time, press and hold the  button, until the hour digits advance to the correct hour, ensuring that AM/PM indicator is correct. (This button will not affect minutes).


Again when the time is displayed, press and hold  button until the minute digits advance to the correct minute. (This button will not affect the hours).



Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Hrs	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on



### STEP 3. Set correct day of week

Press the  button, and advance the day

indicator to the correct day of the week. Figure 6 shows the indicator at Sunday.




Figure 6.

Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Hrs	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on







### STEP 4. Select heat/cool system

By consecutively pressing and releasing the  button the following symbols will appear in this order on your display.

HEAT	AUTO	EMERGENCY	OFF	COOL
		HEAT 	(no symbols)	
		(flashing)		



Select and display your system requirements ie, heat only, cool only, or heating and cooling (auto change over).


#### NOTE


- The battery symbol will show when power is off.
- Battery symbol will flash to indicate weak battery.
- When no heat or cool symbol is displayed, the system is off.
- If you have  only or  only displayed, you will program one temperature and the time. If you have both  and  (auto change over) you will first program heat, then cool, and then the times.

For the following steps, refer to your personal schedule on page 4.

## STEP 5. Enter your A program temperatures



This sequence assumes that you selected the auto  

mode in step 4. If you have heat only 



selected you will program just the heat temperature by skipping substeps (3) and (4). If you have cool only  selected

you will program just the cool temperature by skipping substeps (1) and (2).

(1) Press and release . You will observe a display as in figure 7. This is the heat temperature.

(2) Press  to raise or  to lower to the desired temperature.

(3) Press and release . You will observe a display as in figure 8. This is the cool temperature.


(4) Press  to raise or  to lower to the desired temperature.



**Note:** the thermostat's design will not allow the heat and cool setpoints to be set closer than 2°F or 1°C.

**Caution:** We recommend that in residential use you do not have the heat and cool setpoints closer than 4°F or 2°C.

## STEP 6. Enter Sunday A program time

(1) Press and release 

(2) Press  and advance the day indicator to the left hand position (Sunday). You will see a display as in figure 9.

(3) Press  to advance hours and  to advance minutes (10 minute increments) to the desired start time. You have now entered the Sunday A time.

### Skipping a program

When advancing the minutes between 50 and 00, you will see a display as in figure 10. This means that the program will be skipped. However, the temperatures will still be available for OVERRIDE.





Figure 7. Heat set point




Figure 8. Cool set point



Figure 9. Time

**Note:** These displays are typical only. What you observe will differ if someone has already programmed the thermostat or if your system selection is not heat/cool (see step 4).






Figure 10. Program skipped

Push  to exit skip mode.


Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Mts	B
Select Day Set Override Days	
Resume Program Display Override	
Select	on/auto



## STEP 7. Enter the A times for the balance of the week

- (1) Press to advance the day indicator to Weekdays.
- (2) Press to advance hours and to advance minutes (10 minute increments) to the desired start time.
- (3) In a similar fashion program the time for Saturday by advancing the day indicator with and repeating substep (2).

Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Mts	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on/auto




## STEP 8. Enter B, C, and D temperatures and times

Repeat steps 5 to 7 substituting , , or for .

**Note:** and times for Saturday and Sunday are in the factory set skip mode -----  
To get out of skip mode, press when ----- is displayed. Now set the desired time.

Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Mts	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	on/auto



## STEP 9. Return to normal operation

Press and the display will alternate between temperature and time and control of your environment will be automatic as programmed.

## STEP 10. Override

At any time you may override the scheduled program by merely pressing the program button **A** **B** **C** or **D** with the temperature you wish to hold. The display will then only show that temperature. The temperature will now control at the selected program temperature until you press **■** or the override time elapses.

### Enter timed override

Note: An override time of 00.00 as in figure 11 will give a continuous override.

- (1) Press **■** until you observe your display as in figure 12.
- (2) Press and hold **▲** until the desired hours of override are shown in two right digits.
- (3) Press **☐** until the desired days of override are shown.

Figure 12 shows the factory setting of 3 hours of timed override and no days. Any time the override is used, (by simply pressing

button **A** **B** **C** or **D** which has the desired temperature) the temperature called for will control for 3 hours and then the normal program will resume again.

## STEP 11. Verify Your Programs

- (1) Press **A** and check that it shows your desired heat temperature.
- (2) Press **A** again and check your cool setpoint.
- (3) Press **A** again and check your Saturday time.
- (4) Press **☐** **Note:** Ensure AM/PM is correct and check your Sunday time.
- (5) Press **☐** again and check your weekdays time.
- (6) In a similar manner, check your times and temperatures for B, C, and D.

Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	<b>A</b>
Lower Temp Adjust Mts	<b>B</b>
Select Day Set Override Days	<b>C</b>
Resume Program Display Override	<b>D</b>
Select	<b>on/auto</b>




Figure 11.  
Continuous override





Figure 12.  
Timed override



Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	<b>A</b>
Lower Temp Adjust Mts	<b>B</b>
Select Day Set Override Days	<b>C</b>
Resume Program Display Override	<b>D</b>
Select	<b>on/auto</b>



Write in your heat/cool temperatures in pencil.

# Using some special features

Functions	Programs
Raise Temp Adjust Hrs Set Override Hrs	A
Lower Temp Adjust Mts	B
Select Day Set Override Days	C
Resume Program Display Override	D
Select	or/ auto



## FAN OPERATION

To select FAN ON press . The fan will operate continuously and the fan symbol will be displayed. To select FAN AUTO, which operates the fan only when the system is running, press a second time and the fan symbol will disappear.

## BATTERY

The battery symbol indicates two conditions. If it is flashing, it indicates a missing or low battery condition. When this condition occurs, go to BATTERY INSTALLATION AND START-UP for instructions on how to replace the battery. If the battery symbol is displayed continuously, it indicates that the power is off and that the thermostat is maintaining its memory using the battery. A fresh battery will last 5 to 10 days without power to the thermostat. With continuous power the battery should last two to three years.


**Caution:** use alkaline battery only.

## KEYBOARD LOCK

Keyboard buttons



can be disabled by setting side switch #8 ON. This prevents the program from being altered by unauthorized people.



REMOTE SENSOR  
ACTUAL SIZE SHOWN

## REMOTE SENSOR Model RSK4

If you are planning on installing a remote sensor you must use a two conductor shielded and insulated cable with shield wire. Thermostat wire is not suitable for the remote sensor. Follow instructions that come with the sensor.

Suggest Belden 8760 or 8761 cable or equivalent.

# Installation instructions

- We recommend installer be a trained, experienced service technician.
- Disconnect power supply to systems before beginning installation to prevent personal injury or death from electrical shock or entanglement in moving parts and to prevent equipment damage.
- Ensure control voltage is 20-30 Vac.

## *Thermostat location*

To ensure proper operation, the thermostat should be mounted on an inside wall in a frequently occupied area of the building. In addition, its position must be at least 18 inches from any outside wall, and approximately five feet above the floor in a location with freely circulating air of an average temperature. Be sure to avoid the locations described below when determining a site for the thermostat.

**CAUTION: ZONE INTEGRITY MUST BE MAINTAINED TO EFFICIENTLY CONTROL UNITS OR GROUPS OF UNITS. UNLESS ZONES OF CONTROL ARE CONSIDERED AND ACCOUNTED FOR, ADJACENT UNITS MAY OPERATE IN HEATING AND COOLING MODES SIMULTANEOUSLY.**

## *Do not locate the thermostat*

- behind doors or in corners where freely circulating air is unavailable.
- where direct sunlight or radiant heat from appliances might affect control operation.
- on an outside wall.
- adjacent to, or in line with, conditioned air discharge grilles, stairwells, or outside doors.
- where its operation may be affected by steam or water pipes or warm air stacks in an adjacent partition space, or by an unheated/uncooled area behind the thermostat.
- where its operation will be affected by the supply air of an adjacent unit.
- near sources of electrical interference such as arcing relay contacts.



# Connecting thermostat

Note: This thermostat requires a connection to the transformer common. Make sure that there are enough conductors in the thermostat cable to include it. A cable of up to 10 conductors may be required.




Figure 13.

1. Make sure the power to the systems is off.
2. Pull front unit off of mounting plate.
3. Determine which of the systems described in table 1 applies to your installation. See table 2 for functional descriptions of the terminals. It may be necessary to obtain schematic diagrams and other information from the heat pump manufacturer to determine installation requirements. The thermostat manufacturer may also from time to time publish wiring information.
4. Determine if and how you want to use the two general purpose indicator lights. See page 13.
5. If there are any special wiring requirements, go to the equipment and perform the wiring.
6. See table 1 below and figure 15 on page 14. Set slide switches 2, 3 and 4 to select one of the four systems. Set slide switch 7 and the wire loop switch to define terminal 6 as B, O, Y or W. Set slide switch 9 to define terminal 5 as either EH or EW. This step is very important. These slide switches must correspond to the output wiring.

Table 1

SYSTEM	OUTPUT TERMINALS									SLIDE SWITCHES		
	1	2	3	4	5	6	7	8	9	2	3	4
Single compressor	X	HP1	AUX	G	E	O/B	—	—	R	OFF	ON	ON
*Add-on single compressor	X	HP1	AUX	G	E	O/B	—	—	R	ON	OFF	OFF
Two compressor	X	HP1	AUX	G	E	O/B	HP2	—	R	ON	ON	OFF
*Add-on two compressor	X	HP1	AUX	G	E	O/B	HP2	—	R	ON	ON	ON

TERMINAL 5 OPTIONS	SLIDE SWITCH 9
EH EW	OFF ON

TERMINAL 6 OPTIONS	SLIDE SWITCH 7	WIRE LOOP SWITCH
O	OFF	OPEN
B	ON	OPEN
Y	OFF	CLOSED
W	ON	CLOSED

\* Add-on systems turn off compressor(s) when auxiliary heat comes on.

7. Identify the wires as per your system in table 1.
8. Position the mounting plate so that all the control and indicator light wires protrude through the centrally located slot (figure 14). Level for appearance and mark the three mounting holes. Drill holes using a 3/16" (5mm) drill bit. Install supplied anchors, reposition the mounting plate and secure it to the wall. Do not overtighten screws.
9. Affix the appropriate output terminal label to your mounting plate. Connect the control wires to the proper output terminals. Connect the indicator light wires if the lights are being used.

Table 2.

OUTPUT TERMINALS	FUNCTIONAL DESCRIPTION
AUX	Energizes when auxiliary heat is required.
R	24 Vac connection for all stages.
HP1	Energizes when 1st stage compressor is required.
G	Energizes on any demand for heating or cooling or when manually activated by the fan button.
HP2	Energizes when 2nd stage compressor is required. Room temperature must be 2°F above setpoint in cooling for HP2 to energize.
O	Energizes continuously in cool mode (for reversing valve).
B	Energizes continuously in heat mode (for reversing valve).
X	24 Vac common connection.
W	Energizes on a demand for heat (energizes compressor and reversing valve).
Y	Energizes on a demand for cool (energizes compressor and reversing valve).
EH	Energizes continuously when in Emergency Heat mode.
EW	Energizes on a demand for heat when in the Emergency Heat mode.





Figure 14. Mounting plate

## Lights



The thermostat has two status indicator lights that can be used to indicate user defined conditions such as equipment failure, dirty filter or an output such as AUX being energized. They are activated by connecting the respective terminal (L1 for the left light and L2 for the right light) to R via an output terminal or an appropriate relay contact. For example, if AUX (terminal 3) is connected to L1, the left light will come on whenever AUX is energized. Label the lights in the area provided on the keypad using a pencil.

# Setting slide switches

10. There are a number of options that you can select with the 10 slide switches (and 1 wire loop switch). The slide switches move up and down very easily using a pen. The ON position is marked on the block that encloses the slide switches (figure 15). Set the slide switches (and wire loop switch if necessary) using the information in figure 15 as your guide. You should have already set some of these options in step 6.

**Note:**

The wire loop switch comes set in the open position from the factory. Most installations require it to be open.

Only turn on switch 8 after the thermostat is programmed.

**Switch 6**

OFF—Cycle rate of 6 cycles per hour (CPH) on auxiliary (AUX) heat.

ON—Cycle rate of 3 CPH on auxiliary heat.

Terminal 6 is:	SLIDE SWITCH 7	WIRE LOOP SWITCH
O	OFF	OPEN
B	ON	OPEN
Y	OFF	CLOSED
W	ON	CLOSED

**Switch 1**

OFF—1st stage cool cycle rate is 3 cycles per hour.

ON—1st stage cool cycle rate is 1.5 CPH.

**Switch 5**

OFF—Temperature displayed in °F.



ON—Temperature displayed in °C.

Switches 2, 3 and 4 see Table 1 on page 12.

**Switch 8**

OFF—Keyboard operates normally.

ON—These buttons are disabled to prevent program tampering:



**Switch 9**

OFF—Terminal 5 is "EH".

ON—Terminal 5 is "EW".

**Switch 10**

ON—Normal operation with internal sensor.

OFF—For use with remote sensor.

Figure 15. Setting switches

# Battery installation & start-up

Figure 16. Start-up display




Figure 17. Rear view of front unit

**CAUTION: UNIT HAS BUILT-IN TIME DELAYS FOR HEAT AND COOL. THEY MAY VARY DEPENDING ON ROOMTEMP RISE OR FALL. DELAYS CAN BE FROM 3 TO 15 MIN. PER STAGE.**

Follow the checkout procedure outlined in Table 3. When the system power is turned on the battery symbol should disappear or flash if the battery is weak or missing. Minimum on and off times have been built into the thermostat to prevent HVAC equipment damage due to short cycling. These delays may be longer than specified if the HVAC equipment has built in delays.

The temperature calibration control shown in figure 17 may be used for minor adjustments. Clockwise rotation will lower the displayed temperature.

11. Install the battery.
12. Allow a few seconds for the display to start flashing once per second (figure 16).
13. Push . The display will alternate every four seconds between room temperature and time.
14. Replace the thermostat front unit on mounting plate.

Table 3

STEP	PUSH BUTTON	DISPLAY SHOWS	RESPONSE
1			Heat mode
2		 	Auto heat/cool mode
3		flashing once per second	Emergency Heat mode — auxiliary stage only
4		(no symbol)	All systems go off after 7 seconds
5			Cool mode
6		select required mode (step 1,2,3 or 5) for further testing	
7		Stationary 68 or 73 (20 or 22.5)	Heating and cooling set-points. Room temperature will be maintained at these set-points
8	 	Increase or decrease of set point temperature	Equipment will respond subject to time delays
9	 hold		<b>Quick Check Start-up</b> Time delays can be reduced to a few seconds by pressing and holding any one of the program buttons A, B, C, or D. Release when the stage indicator is displayed. Care must be taken not to short cycle the compressor. Set-point should be 10° higher than ambient in heating or 10° cooler than ambient in cooling. <b>Note:</b> return temperature to the original setting.
10			Fan runs continuously
11		(no FAN symbol)	Fan operates automatically

# Trouble shooting guide

SYMPTOM	CAUSE	ACTION
UNIT APPEARS OK BUT WILL NOT ACTIVATE RELAYS OR RELAYS CHATTER	1) SOLID STATE SWITCH FAILURE 2) HIGH RESISTANCE AT EQUIPMENT	— REPLACE UNIT — LOAD DOWN RELAY COIL WITH 4700 ohm 1 WATT RESISTOR OR INSTALL ISOLATION RELAY
HEAT OR COOL STATUS INDICATORS WILL NOT APPEAR	1) BUILT IN TIME DELAYS 2) NO 24 VAC	— OVERRIDE USING QUICK CHECK START-UP — TURN ON 24 VAC
SYSTEM CYCLES BEFORE REACHING SETPOINT	BUILT IN COMPUTER RECOVERY	UNIT OPERATING NORMALLY
DISPLAY FLASHING-PROGRAM LOST	1) STATIC ELECTRICITY 2) RADIO FREQUENCY INTERFERENCE	— DISCHARGE BEFORE TOUCHING STAT — USE SHIELDED CABLE WITH REMOTE SENSOR
TEMPERATURE READING INCORRECT	1) OUT OF CALIBRATION 2) EXTERNAL HEAT SOURCE 3) DOWN DRAFT AT THERMOSTAT	— RECALIBRATE WITH ACCURATE THERMOMETER — ISOLATE STAT FROM HEAT SOURCE OR OVERHEAD DIFFUSERS
ERRATIC TEMPERATURE READING	1) WHEN REMOTE SENSOR IS INSTALLED SWITCH #10 MUST BE OFF 2) FAULTY THERMISTOR 3) INCORRECT SHIELDING CONNECTIONS OR SHIELD GOES TO MECHANICAL GROUND	— DISCONNECT REMOTE SENSOR LEADS IF INTERNAL THERMISTOR IS TO BE USED TEMPORARILY — REPLACE OR CHECK WITH OHMMETER (10,000 ohms APPROXIMATE AT 77° F) — CHECK REMOTE SENSOR WIRING
STAT WILL NOT RETURN FROM SETBACK	1) OVERRIDE SET FOR DAYS 2) WRONG DAY OF WEEK	— PRESS RESUME, REMOVE DAYS FROM MEMORY — PRESS DAY KEY AND ADVANCE TO CORRECT DAY
UNIT COOLING IN HEATING MODE AND HEATING IN COOLING MODE	B/O SWITCH SET INCORRECTLY	— SEE FIGURE 15 ON PAGE 14 FOR DETAILS

---

# Specifications

---

Rated voltage	18-30 Vac
Rated current	0.050 — 1.5 Amp continuous for each output with surges to 4 Amps. Maximum 3 Amps continuous total of all outputs.
Cycle rate	3 Cycles per hour
optional	6 CPH on Auxiliary heat
optional	1.5 CPH on 1st compressor in cooling
Minimum on/off times to prevent short cycling	1.5 CPH — 12 minutes 3 CPH — 6 minutes 6 CPH — 3 minutes
Control range	
Heating	42 to 114° F in 1° steps or 7 to 43° C in 0.5° steps
Cooling	44° to 116° F in 1° steps or 8 to 44° C in 0.5° steps
Temperature measurement range	38 to 119° F or 5 to 45.5° C
Accuracy	± 1° F at 68° F or ± 0.5° C at 20° C
Battery	9 volt ALKALINE (Eveready #522 or equivalent) for memory retention during power outage
Quartz clock accuracy	± 80 seconds/month
Range of ambient operation	32 to 131° F (0 to 55° C)
Storage temperature	-30 to 131° F (-34 to 55° C)
Operating humidity range	5 to 90% RH non condensing

Specifications subject to change without notice

---

## enerstat™

Developed and manufactured by  
**Valera Electronics Inc.**,  
5370 Canotek Road,  
Ottawa, Canada K1J 9E7

**Valera Corporation**  
812 Proctor Ave.  
Ogdensburg, New York  
13669

**Valera Corporation Australia Pty. Ltd.**  
Southeast Asia  
37 Benwerrin Drive, Burwood East 3151  
Victoria, Australia